

Controlling The Remote

TV, Set-Top-Box
Use one remote to control multiple devices.

Menu
Displays the menu.

Arrow Keys and OK/Sel
Navigate and select onscreen choices.

Guide
Opens the Interactive Program Guide.

Red, Green, Yellow, Blue
Access additional features on set-top box.

Volume Up and Down
Raise or lower the volume.

On Demand
Access video on demand services.

Mute
Turn the sound off or on.

Aspect Ratio*
Temporarily change the conversion mode from Original Size to Fit Screen.



Off
Turn on/off a selected device.

Info
Display current channel and Program information. Press again for more detail.

Exit
Exit the current screen.

Page +/-
Page up or down in lists and Interactive Program Guide.

Channel Up and Down
Changes to the next higher or lower channel.

Last
Recall the last channel you were watching.

Fav
View your favorite channels.

NumberKeys (0-9)
Directly select a channel or enter options.

Input
In TV control mode, will change the input of the device you are controlling.



WHAT'S ON TV?

There's more than one way to see what's showing on TV.

Info Button:

Press Info and you will see the name and a description of the current program at the top of the screen.

OK Button:

Press OK to show the 'Now Playing' bar and you will see what program is currently playing.

Guide Button:

This is the most comprehensive view of what's on. Go ahead and page through... you're bound to find something to watch.

Browse Button:

Press Browse (right arrow) to show the channel you are currently tuned to at the top of the screen. At the bottom of the screen, the 'Info Bar' shows you the channel number, channel name, current date and time, program name, date and time the program airs, a progress bar, and the program that airs next.

*If Available